



Triton Blue Mini Spot 250 SP



Características

Canales DMX: 11, Conexión DMX 512: XLR 3 Vías.

Pan 360° / Tilt 256°. Alta velocidad en movimiento Pan y Tilt.

Alta velocidad en movimiento Pan y Tilt.

Rueda con 9 colores más blanco, más efecto rainbow.

Rueda de gobos rotativos: 7 gobos más abierto. Diámetro exterior de los gobos: 25 mm, diámetro del imagen de los gobos: 20 mm

Frecuencia de flash / Strobe: 13 Hz.

Programación automática.

Pantalla: dirección digital y configuración de las funciones.

Resét local o remoto.

Interruptor local de encendido y apagado.

Auto test de todas las funciones.

Muestra de cada uno de los valores de los canales DMX.

Almacenamiento de programas: Edición y almacenamiento de programas para incorporar en la EEPROM a través del control en el panel frontal o un controlador externo, puede salvar un máximo de 48 escenas, y ejecutar los programas almacenados con la opción "RUN" del panel frontal.

Alimentación: 230 V/50 hz.


Consumo: 400 W

Dimensiones: 380 x 330 x 450 mm


Peso: 15 Kg.

Fusible: T 4 A, 250 V

Datos fotometricos



Dimensiones



Lista canales

%	1 Color	2 Gobo	3 Gobo Rotation	4 Strobe	5 Pan	6 Tilt	7 Movement Speed	8 Prism Macro	9 FOCUS ZOOM	10 Dimming	11 Internal Program
100%	[Color wheel icon]	[Gobo wheel icon]	[Gobo rotation icon]	[Strobe icon]	[Pan icon]	[Tilt icon]	BLACKOUT BY WIRE CHANGING BLACKOUT BY MOVEMENT	MARCO1 MARCO2 MARCO3 MARCO4 MARCO5 MARCO6 MARCO7	ZOOM1 ZOOM2 ZOOM3 ZOOM4 ZOOM5 ZOOM6 ZOOM7	[Dimmer icon]	AUTO PROGRAMS OF MUSIC Program 1 Program 2 Program 3 Program 4 Program 5 Program 6 Program 7 Program 8 Program 9 Program 10 Program 11 Program 12 Program 13 Program 14 Program 15 Program 16 Program 17 Program 18 Program 19 Program 20 Program 21 Program 22 Program 23 Program 24 Program 25 Program 26 Program 27 Program 28 Program 29 Program 30 Program 31 Program 32 Program 33 Program 34 Program 35 Program 36 Program 37 Program 38 Program 39 Program 40 Program 41 Program 42 Program 43 Program 44 Program 45 Program 46 Program 47 Program 48 Program 49 Program 50 Program 51 Program 52 Program 53 Program 54 Program 55 Program 56 Program 57 Program 58 Program 59 Program 60 Program 61 Program 62 Program 63 Program 64 Program 65 Program 66 Program 67 Program 68 Program 69 Program 70 Program 71 Program 72 Program 73 Program 74 Program 75 Program 76 Program 77 Program 78 Program 79 Program 80 Program 81 Program 82 Program 83 Program 84 Program 85 Program 86 Program 87 Program 88 Program 89 Program 90 Program 91 Program 92 Program 93 Program 94 Program 95 Program 96 Program 97 Program 98 Program 99 Program 100
75%											
50%											
25%											
0%											

1 - Rueda de Color	2 - Gobos
3 - Rotación gobos	4 - Strobe
5 - Pan	6 - Tilt
7 - Speed	8 - Macros de prisma
9 - Focus / Zoom	10 - Dimmer
11 - Auto programas	