



Detalles de producto **EMH 575W/SE/75**



Nombre: EMH 575W/SE/75
Nro de Producto: 4008321345080
Cantidad solicitada: Estuche de cartón (FS) contiene 1 Unidad (ST)

Aplicaciones	
Posición de funcionamiento	Universal

Categorizations	
NAED	57027

Descripción general	
Casquillo (denominación estándar)	GX9.5
Lamp reference type	HSR 575W/72

Datos logísticos	
Peso del producto	90 g

Datos técnicos eléctricos	
Tensión de construcción	97.5 V
Potencia de la lámpara	575 W
Tensión de funcionamiento	95 V
Corriente de construcción	6.1 A
Lamp current	7.0 A
Potencia de construcción	575 W

Geometrías	
Diámetro	28 mm
Longitud con casquillo pero sin pitones/	125 mm
Longitud del filamento	7.00 mm
Distancia al centro del cuerpo luminoso	65 mm
Longitud	125 mm

Duración	
Duración	750 h

Datos técnicos de iluminación	
Flujo luminoso en lm	42000 lm
Temperatura de color	7500 K
Luminancia	10000 cd/cm ²
Índice de reproducción cromática Ra	70

Opciones de embalaje				
Product code	Tipo de embalaje y contenido	Dimensión en a x a x l	Peso bruto	Volumen
4008321345080	Estuche de cartón contiene 1 Unidad	79,000 mm x 51,000 mm x 156,000 mm	142,000 g (0,000 g)	0,629 dm ³
4008321345097	Embalaje de envío contiene 10 Unidad	245,000 mm x 194,000 mm x 327,000 mm	1,594,000 g (0,000 g)	15,542 dm ³





Detalles de producto **EMH 575W/SE/75**

EMH lamps are short arc lamps in which the discharge arc burns in an atmosphere of mercury vapor and various halide additives at high pressure (no overpressure with a cold lamp).

The most important properties and benefits

- EMH provides effective high-quality light at an attractive price (EMH = Economy Metal Halide)
- EMH lamps are economical versions of the most popular metal halide lamps. They are powerful and durable. EMH lamps also reflect the high quality for which the name of OSRAM is widely famous
- Thanks to their excellent price/performance ratio EMH lamps are ideal for use in clubs, shops and small stages
- EMH lamps are available in different wattages and color temperatures, in single-ended and double-ended versions

Safety

Because of their high luminance, UV radiation and high internal pressure during operation EMH lamps may only be operated in enclosed lamp casings specially constructed for the purpose. Appropriate filters must ensure that UV radiation is reduced to an acceptable level. Mercury is released if the lamp breaks. Special safety precautions must be taken. More information is available on request or can be found in the leaflet included with the lamp or in the operating instructions.

Literature

Further technical information on EMH lamps and information for manufacturers of operating equipment can be requested directly from OSRAM.